

BELOW KNEE SUCTION INSTRUCTIONS

PUTTING YOUR PROSTHESIS ON



1. Turn the liner
inside out.



2. Place completely
inverted liner against
your skin, grip lightly
and roll on.



3. Grip lightly and roll it
on. Check for wrinkles.
*Do not trap air in bottom
of the liner*



4. Apply the correct ply of
socks acting as a wick &
fitting aid.



5. Make sure there are
no wrinkles in the sock.



5. Pull down the sealing
sleeve & protective sleeve
(if equipped) from socket.



6. Insert residual limb
into socket with sock
on outside of liner.



7. Roll up the (Gator)
protector sleeve. (if
equipped)



8. Roll/Slide the sealing
sleeve over residual
limb. Ensure there are
no wrinkles in sleeve.



9. Finished &
ready for use.

TIPS

- The sealing sleeve MUST make contact with a minimum of 1 1/2" of either the liner or your leg to seal.
- The sock must be 1 1/2" *BELOW* the top of sealing sleeve. IF THE SOCK IS NOT BELOW THE TOP OF SLEEVE IT WILL LEAK.

TAKING YOUR PROSTHESIS OFF

1. Sit down
2. Slide the sealing sleeve down just below the back rim of the socket
3. Slide the gator protective sleeve down (if equipped)
4. Push the prosthesis off
5. Pull off all socks
6. Slide off the liner
7. Inspect skin *If there is redness that doesn't Blanche or go away after 10 minutes discontinue prosthetic use & call your Prosthetist immediately*

Teitelbaum Orthotics & Prosthetics

Locations:

Williamsburg - 166 Ross St, Brooklyn, NY 11211, USA

Boro Park - 910 46th St, Brooklyn, NY 11219, USA

Monsey - 41 Main St, Monsey, NY 10952, USA

Call: +1 718-782-0600

Fax: +1 718-782-0611